



## **Drive-Thru Communication System**

## BELT-PAC AND HEADSET OPERATION:

- Talk to customers A1 or A2
- Talk to crew B
- Volume up ▲ or ∧
- Volume down ▼ or V
- Power on/off PWR or red button






One-Touch Hands Free	Push To Talk	Auto Hands Free
With power off Press (ΔorΛ) + B + Power Release buttons	With power off Press (▼orV) + B + Power Release buttons	With power off Press (▲orΛ) + (A1/A2) + Power (A1 for Lane 1 – A2 for Lane 2) Release buttons
In this mode, press and release A1 or A2 button to talk to customer	In this mode, press and hold A1 or A2 button to talk to customer	In this mode, talk to customer without pressing buttons
Customer arrives Alert tone in headset Touch-Release A1 or A2 Speak/Listen to customer Touch-Release A1/A2 or B Communication ends	Customer arrives Alert tone in headset Press & hold A1 or A2 Speak to customer Release to listen	Customer arrives Alert tone in headset Speak/Listen to customer Touch-Release A1/A2 or B Communication ends
In Tandem operations, Order Taker #1 uses the A1 button for customers at order point #1 and Order Taker #2 uses the A2 button for customers at order point #2		In Tandem operations, only Order Taker #1 can operate in the Auto Hands Free mode
Customer arrives Alert tone in headset 1 beep = Lane 1 2 beeps = Lane 2 Touch-Release A1 for Lane 1 Touch-Release A2 for Lane 2 Touch-Release opposite button to change lanes Speak/Listen to customer Touch-Release A1/A2 or B Communication ends	Customer arrives Alert tone in headset 1 beep = Lane 1 2 beeps = Lane 2 Press & hold A1 for Lane 1 Press & hold A2 for Lane 2 Speak to customer Release A1/A2 to listen	Customer arrives Alert tone in headset 1 beep = Lane 1 2 beeps = Lane 2 Speak/Listen to customer Touch-Release A1/A2 or B Communication ends
With power off Press B + A2 + Power Release buttons Touch-Release B to speak/listen to crew Touch-release B again	With power off Press B + A2 + Power Release buttons Press & hold B to speak to crew Release to listen	
	With power off Press (▲orA) + B + Power Release buttons  In this mode, press and release A1 or A2 button to talk to customer  Customer arrives Alert tone in headset Touch-Release A1 or A2 Speak/Listen to customer  Touch-Release A1/A2 or B Communication ends  In Tandem operations, Order of customers at order point #1 a button for custome  Customer arrives Alert tone in headset 1 beep = Lane 1 2 beeps = Lane 2  Touch-Release A1 for Lane 1 Touch-Release A2 for Lane 2 Touch-Release A2 for Lane 2 Touch-Release A1/A2 or B Communication ends  With power off Press B + A2 + Power Release buttons Touch-Release B to speak/listen to crew Touch-release B again	With power off Press (▲orA) + B + Power Release buttons    In this mode, press and release A1 or A2 button to talk to customer   Customer arrives Alert tone in headset Touch-Release A1 or A2 Speak/Listen to customer   In Tandem operations, Order Taker #1 uses the A1 button for customers at order point #1 and Order Taker #2 uses the A2 button for customers at order point #2    Customer arrives Alert tone in headset 1 beep = Lane 1 2 beeps = Lane 2 Touch-Release A1 for Lane 1 Touch-Release A2 for Lane 2 Touch-Release A2 for Lane 2 Touch-Release A2 for Lane 2 Touch-Release A1/A2 or B Communication ends    With power off Press B + A2 + Power Release buttons

# COMMUNICATOR® STATUS: With power off • Press A2 + (▼or V) + Power • Release buttons

### **CHANGE BATTERY:**

If you hear "Battery low" or "Change battery" -

- Press battery-release button and remove battery
- Place battery in battery-charger for recharging
- Install fully charged battery in belt-pac or headset









## Système de communication de Service Au Volant

#### MODE D'EMPLOI POUR APPAREIL DE CEINTURE ET ECOUTEUR:

- Parlez aux clients = A1 ou A2
- Parlez aux employes = B
- Monter volume = ▲ ou ∧
- Baisser volume = ▼ ou V
- Allumer/eteindre = PWR ou buton rouge







Coffret de ceinture

Mode

Système

avec une

seule voie

Mode d'installation

Une Touche Mains Libres

Appareil eteint appuyez sur  $(\triangle/\Lambda) + B + PWR$  (bouton rouge) Relachez les boutons

Appuyez Pour Parler Appareil eteint appuyez sur  $(\nabla/V) + B + PWR$  (bouton rouge) Relachez les boutons

Appareil eteint appuyez sur  $(\triangle/\Lambda)$  + (A1/A2) + PWR (bouton rouge) (A1 pour Voie 1, A2 pour Voie 2) Relachez les boutons

Dans ce mode, appuyez et relachez les boutons A1 ou A2

pour parler aux clients Client arrive Ton d'alerte dans l'écouteur

Appuyez-Relachez A1 ou A2 Parlez/Ecoutez le client Appuvez/Relacher A1 ou A2 ou B pour terminar la communication

Dans ce mode, appuyez et retenez les boutons A1 ou A2 pour parler aux clients

Client arrive Ton d'alerte dans l'écouteur Appuyez et retenir A1 ou A2 Parlez au client Relachez pour ecouter

Dans ce mode, parlez au client sans toucher aux boutons

Client arrive

Ton d'alerte dans l'écouteur Parler/Ecouter le client Appuyez/Relachez A1 ou A2 ou B pour terminer la communication

Dans les installations Tandem, le preneur de commande numéro 1 utilise le bouton A1 pour les clients au point de commande numéro 1 et le preneur de commande numéro 2 utilise le bouton A2 pour les clients au point de commande numéro 2

Dans les installations Tandem, seul le preneur de commande numero 1 peut fonctionner en Mode Mains Libres Automatique

Système à Deux Voies

1 son = Voie 12 sons = Voie 2 Appuyez-Relachez A1 pour Voie 1 Appuyez-Relachez A2 pour Voie 2 appuyez-relachez le bouton oppose pour changer de voie Parlez/Ecoutez le client Appuyez-Relachez A1/A2 ou B pour terminer la communication

Ton d'alerte dans l'écouteur

Client arrive Ton d'alerte dans l'écouteur 1 son = Voie 1

2 sons = Voie 2 Appuyez et retenez A1 pour Voie 1 Parlez/Ecoutez le client Appuyez et retenez A2 pour Voie 2 Appuyez-Relachez A1/A2 ou B Parlez au client Relachez A1/A2 pour ecouter

Client arrive

Ton d'alerte dans l'écouteur 1 son = Voie 1

2 sons = Voie 2

pour terminer la communication

Communiquer avec les employés

Pour eteindre l'appareil appuyez sur B + A2 + PWR Relachez les boutons Appuvez-relachez B pour parler/ecouter les employes Appuyez-relachez B de nouveau pour terminer la communication Pour eteindre l'appareil, appuyez sur B + A2 + PWR Relachez les boutons Appuyez et retenez B pour parler aux employes Relachez pour ecouter

ETAT DU COMMUNICATEUR: Eteint — Appuyez sur A2 + (▼ ou V) + PWR (bouton rouge) — Relachez les boutons

#### CHANGER LES PILES:

Si vous entendez « changez les piles » ou « niveau de batterie bas » dans votre écouteur;

Client arrive

- Appuyez sur le bouton deverrouillage de batterie et retirez la batterie
- Placez les piles dans le chargeur de piles
- Installez les piles completement chargees soit dans l'appareil de ceinture ou l'écouteur



Bouton de deverrouillage de la batterie

